

Manufacturer	Model	Wheelbase	WB Length	Floor Length	Innotrax Full Floor	Body Mounted 3rd Point	Crew Cab Part Floor	Innotrax Flat Floor	Suspension Kit (Required for Flat Floor)	Low Profile Rail Installation	Surface Rail Installation	Heavy Duty Rail Installation	Solo Anchors Installation	Witness Report Available
Citroen	Jumper/Relay 2006 -	SWB MWB LWB	3000 3450 4035	2670 3120 3705	Y	GR	Y	N	N	N	N	N	N	Y
Citroen	Jumpy/Dispatch 2007 -2015	SWB LWB	3000 3122	2254 2584	Y	GR	Y	N	N	N	N	N	N	Y
Citroen	Dispatch 2016-	SWB LWB	3000 3122	2254 2584	N	N	N	N	N	N	N	N	N	N
Fiat	Ducato 2006 -	SWB MWB	3000 3450	2670 3120	Y	Y	Y	N	N	N	N	N	N	Y
Fiat	Scudo 2007-2015	LWB SWB LWB	4035 2824 3224	3705 2250 2580	Y	N	Y	N	N	N	N	N	N	Y
Ford	Transit 2013 -	MWB LWB XLWB	3300 3750 3750	2949 3399 4107	Y	B	Y	Y	N	N	N	N	N	Y
Ford	Transit Custom 2012 -	SWB LWB	2933 3300	2555 2720	Y	GN	Y	N	N	N	N	N	N	Y
Iveco	Daily 2009-2014	SWB MWB LWB	3000 3300 3950	3000 3560 4560	Y	GR	Y	Y	N	N	N	N	N	Y
Iveco	Daily 2014 -	SWB MWB LWB XLWB	3000 3520 4100 4100	2600 3540 4680 5125	N	B	N	Y	N	N	N	N	N	Y
Mercedes	Sprinter 2006 -	SWB MWB LWB XLWB	3250 3665 4325 4325	2600 3265 4300 4700	Y	GR	Y	Y	Y	N	N	N	N	Y
Mercedes	V Class, Vito, 2003 -2015	SWB MWB LWB	3200 3200 3430	2422 2670 2850	Y	N	Y	N	N	N	N	N	N	Y
Mercedes	V Class, Vito, 2015-	SWB MWB LWB	3200 3200 3430	2422 2670 2850	N	N	N	N	N	N	N	N	N	N
Nissan	NV400 2015 -	SWB MWB LWB XLWB			Y	B	Y	Y	N	N	N	N	N	Y
Nissan	Primastar 2001-2014	SWB LWB	3198 2598	2400 2800	Y	N	Y	N	N	N	N	N	N	Y
Nissan	Primastar 2014 -	SWB LWB			N	N	N	N	N	N	N	N	N	N
Peugeot	Boxer 2006 -	SWB MWB LWB	3000 3450 4035	2670 3120 3705	Y	GR	Y	N	N	N	N	N	N	Y
Peugeot	Expert 2007 -2015	SWB LWB	3000 3122	2254 2584	Y	N	Y	N	N	N	N	N	N	Y
Peugeot	Expert 2015-	SWB LWB	3000 3122	2254 2584	N	N	N	N	N	N	N	N	N	N
Renault	Master 2010 -	SWB MWB LWB	3182 3682 4332	3733 3733	Y	B	Y	Y	N	N	N	N	N	Y
Renault	Traffic 2001-2014	SWB LWB	3100 3500	2400 2800	N	N	Y	N	N	N	N	N	N	Y
Renault	Traffic 2014 -	SWB LWB			N	N	N	N	N	N	N	N	N	N
Vauxhall	Movano 2010 -	SWB MWB LWB	3080 3580 4080	2710 3210 3710	Y	B	Y	Y	N	N	N	N	N	Y
Vauxhall	Vivaro 2001-2014	SWB LWB	3100 3500	2400 2800	Y	N	Y	N	N	N	N	N	N	Y
Vauxhall	Vivaro 2014 -	SWB LWB			N	N	N	N	N	N	N	N	N	N
Volkswagen	Crafter 2006 -	SWB MWB LWB XLWB	3250 3665 4325 4325	2600 3265 4300 4700	Y	GR	Y	Y	Y	N	N	N	N	Y
Volkswagen	T5 /T6/ Transporter 2003 -	SWB LWB	3000 3400	2543 2943	Y	W	Y	N	N	N	N	N	N	Y

Key: B = Bolted, GR = Glued & Rivet, GN = Glued and Rivnut, W= Welded

Released: 10/11/17

Vauxhall	Movano 2010 -			SWB	3080	2710	VCA-ESQ309638 (31/3/2015) TUV-(Awaiting Report) UTAC 14-09369 and 14-09283 (23/3/2016)	B	VCA-ESQ309638 (31/3/2015)	VCA-ESQ321889 (12/3/2015) UTAC 16-01144 and 16-01144 (15/2/2016) TUV (Awaiting Report)	N	N	N	N	N	Y	
				MWB	3580	3210											
				LWB	4080	3710											
Vauxhall	Vivaro 2001-2014			SWB	3100	2400	VCA-ED052800 (14/08/2003) TUV-45SG0563-03 (11/11/2010)	N	VCA-ESP294693 (04/07/2014)	N	N	N	N	N	N	Y	
				LWB	3500	2800											
Vauxhall	Vivaro 2014 -			SWB			N	N	N	N	N	N	N	N	N	N	
				LWB													
Volkswagen	Crafter 2006 -			SWB	3250	2600	VCA-ESG 078521 (12/9/2006) TUV-45SG0563-03 (11/11/2010)	GR	VCA-ESP294693 (04/07/2014)	VCA-ESH184491 (21/11/2007) TUV 95XS0070-01 (10/11/2010)	Y	N	N	N	N	N	Y
				MWB	3665	3265											
				LWB	4325	4300											
				XLWB	4325	4700											
Volkswagen	T5 /T6/ Transporter 2003 -			SWB	3000	2543	VCA-ED052800 (14/08/2003) TUV-45SG0563-03 (11/11/2010)	W	VCA-ESP294693 (04/07/2014)	N	N	N	N	N	N	Y	
				LWB	3400	2943											

Key: B = Bolted, GR = Glued & Rivet, GN = Glued and Rivnut, W= Welded

Released: 10/11/2017